

# UDC 1000 TAC TIP

Model DC100L

## How to set a Limit Setpoint

1. Hold down the “↑” and the **SET UP**” key. Set the “**Uloc**” to your Lockout code ,using the ↑ ↓ keys. The default is 10.
2. When the **Uloc** value is set, press the **SET UP** key.
3. **SP** is in the lower display. Set this to where you want the Limit Relay to trip.
4. Press the **SET UP**” key to store the value.
5. Press the “**SET UP**” key until the Process Variable is in the Upper display.
6. To Exit: Hold down the “↑” and the press the “**SET UP**” key.