

Setting Input 1 & 2 Hardware

Dual jumper for Input 1 and Input 2

Depending on the type of input actuation or range that you are selecting, install or remove the dual jumper at the desired position on the controller board. Refer to Figure 2-3 and follow the procedure in Table 2-3.

Table 2-3 Installing or Removing Dual Jumper for Input 1 and 2

Step	Action
1	Locate the two dual jumper positions identified as W204/W205 and W206/W207 on the rear of the controller board (see Figure 2-3) ATTENTION The white lines on the top of the jumper must be vertical for proper continuity.
2	Determine which of the two dual jumper positions on the controller board is applicable to the input circuit that you want to change: INPUT NO. 1: Position W206/W207 INPUT NO. 2: Position W204/W205 Refer to Figure 2-3 for jumper selection.
3	Install or remove the jumper(s).

Figure 2-3 Dual Jumper Location

