

7.7 Printing Characteristics Adjustments

Printing characteristics adjustments

Normally there is no need to adjust the printing characteristics as part of an input or output calibration procedure. However, if the chart printing appears to be faded, you can use the procedure in *Section 4 - Configuration Definitions*, Table 4-12 to make slight adjustments in the print contrast.

ATTENTION To access Set Up group prompt "ADJUST", the Set Up group prompt "LOCKOUT" must be set to "NONE". If the group prompt "LOCKOUT" has been configured for "CALIB", "+VIEW", or "MAX" selection, you will not be able to access the Printing Characteristics Group prompt. Refer to *Section 3 - Configuration* for details.
