



	Positions	
AI = Analog input	From A to F	(Lower rack)
AO = Auxiliary output	From N to P	(Upper rack)
DI = Digital input	From J to P	(Upper rack)
DO = Digital output (relay)	From J to P	(Upper rack)

Note: Terminal blocks can be removed from the board for easier wiring and board replacement