



Positions	
AI = Analog input	From A to H (Lower rack) and from J to R (Upper rack)
AO = Auxiliary output	From N to R (Upper rack)
DI = Digital input	From J to R (Upper rack)
DO = Digital output (relay)	From J to R (Upper rack)

Note: Terminal blocks can be removed from the board for easier wiring and board replacement