

Parts list




Figure	Part Number	Description
1	81401280-002	Door
2	81401823-5P4	Range Board RTD
	-5K0	K -199.9 to 200°C
	-5E0	E 0 to 1200°C
	-5R1	R 0 to 800°C
	-5J0	J 0 to 1600°C
	-5W2	W ₅ W ₂₆ 0 to 800°C
	-5B1	B 0 to 2300°C
	-5T4	T 0 to 1800°C
	-5S1	S -200 to 300°C
	-5C0	mA 0 to 1600°C
	-5V0	V 4-20 mA
	-5M0	mV 1-5V
	-5BF	B 0-10 mV
	-5HF	B 0 to 3300°F
	-5EF	RTD -300 to 900°F
	-5RF	E 0 to 1800°F
	-5JF	R 0 to 3100°F
	-5WF	J 0 to 1600°F
	-5TF	W ₅ W ₂₆ 0 to 3300°F
	-5SF	T -300 to 700°F
	-5ZF	S 0 to 3100°F
		Ni/NiMo 0 to 2500°F
3	81401821A	I/O Board
4	81401820-031	CPU Board, °F
	-041	°C, Linear
5	81401822A	Power Supply Board
6	81401405-102	Case
7	81401281-0T5	Back Panel Thermocouple
	-0P5	Linear, RTD
8	187398C	Resistor Compensation
9	81400836A	Battery