

DIALATROL TO UDC3300 POSITION PROP. CONVERSION

DIALATROL TERMINAL	UDC3300 TERMINAL
1	26
2	27
3	25
4	22
5	23
6	24
7	3
8	6
9	2 & 5
10	7
11	8
12	9
13	23
14	24
15	
16	16
17	17
L1	L1
L2	L2
GND.	GND