




UDC 3500 Application Note

Removing the chassis



Insert thin screwdriver under tabs and twist *slightly and gently* to disengage front

Using a thin screwdriver, *gently* twist the screwdriver to pry the side tabs from the front face. Pry just enough to release it, *otherwise you'll bend or break the tab*. If you break or bend the tab and can't reattach the front snugly, you'll need to reattach the front using the 4 NEMA4 screws provided.